



F1



F2

**F1**  
Pine  
Flat Screen Moulding  
 $1\frac{1}{4}'' \times 3\frac{1}{4}''$

**F3**  
Pine  
Square Stop  
 $1\frac{1}{2}'' \times 1\frac{1}{2}''$

**F5**  
Pine  
Square Stop  
 $3\frac{1}{4}'' \times 3\frac{1}{4}''$

**F7**  
Pine  
Lattice  
 $1\frac{1}{4}'' \times 1\frac{3}{4}''$

**F2**  
Pine  
"Beaded" Screen Moulding  
 $1\frac{1}{4}'' \times 3\frac{1}{4}''$

**F4**  
Pine  
Stop  
 $1\frac{1}{2}'' \times 3\frac{1}{4}''$

**F5R**  
Redwood/Red Cedar  
Square Stop  
 $3\frac{1}{4}'' \times 3\frac{1}{4}''$


**F7R**  
Redwood/Red Cedar  
Lattice  
 $1\frac{1}{4}'' \times 1\frac{3}{4}''$



F3



F4



F5  
F5R



F6

**F8**  
Redwood/Red Cedar  
Resawn Batten  
 $1\frac{1}{4}'' \times 2\frac{1}{2}''$

**F9**  
Redwood/Red Cedar  
Lattice  
 $1\frac{1}{4}'' \times 1\frac{3}{8}''$

**F6**  
Pine  
Lattice  
 $1\frac{1}{4}'' \times 1\frac{3}{8}''$



F7  
F7R

**F11**  
Pine  
Lattice  
 $2\frac{1}{4}''$



F8


**L118**  
Oak  
S4S Square Stop  
 $3\frac{1}{4}'' \times 3\frac{1}{4}''$



F9



F11



L118